



Main location /distribution point

freesat digibox  
(Room Layout 1)

freesat TV  
(Room Layout 2)

Terrestrial TV only  
(Room Layout 3)

NOTE:  
In rooms with no Sky or freesat receiver (decoder box or built in to TV) do not connect the LoftBox Expander as this will prevent the use of tvLINK sensors

**CyberSelect**  
technology for the home

Freesat and multiple distributed Sky to eight locations. IR control over conventional TV distribution system. Single cable to each of the remote locations.

Reference	Freesat 4c (Labgear)
Date Created	30 April 2010
Date Modified	07 May 2010

© Copyright 2010