

PLASTIC LOW VOLTAGE MOUNTING PLATE BRACKETS

For use with low voltage systems
where electrical boxes are not
required.

SIZING CHART

PART NO.	FIG.	DESCRIPTION
MP1P	1	SINGLE GANG MOUNTING PLATE
MPAL2	2	DOUBLE GANG MOUNTING PLATE
MP34P	3	3 OR 4 GANG MOUNTING PLATE

For low voltage class 2 use only.

Mounts standard plates for low voltage systems.
Used with T.V. antennas, phone jacks,
computer outlets and sound systems.

FIG. 1




FIG. 2







FIG. 3




Easy to install. Only a drywall saw is required.




BREAK OFF
ALL LOCKING
TABS




PUSH POINTS
AGAINST WALL




CONNECT MARKS,
CUT OPENING



SLIDE LOCKING
TABS OVER
THE FIRST FEW (3-4)
TEETH ONLY



SQUEEZE
THROUGH
OPENING



DRAW TABS
FIRMLY AGAINST
DRY WALL

INSTALL
WALL PLATE

WARNING

1. ERICO products shall be installed and used only as indicated in ERICO product instruction sheets and training materials. Instruction sheets are available at www.erico.com and from your ERICO customer service representative.
2. ERICO products must never be used for a purpose other than the purpose for which they were designed or in a manner that exceeds specified load ratings.
3. All instructions must be completely followed to ensure proper and safe installation and performance.
4. Improper installation, misuse, misapplication or other failure to completely follow ERICO's instructions and warnings may cause product malfunction, property damage, serious bodily injury and death.
5. Products that are manufactured using spring steel components shall be used only in a non-corrosive indoor environment.
6. All pipe supports, hangers, intermediate components and structural attachments must ONLY be used as described herein and are NEVER to be used for any other purpose.

NOTE: All load ratings are for static conditions and do not account for dynamic loading such as wind, water or seismic loads, unless otherwise noted.

The customer is responsible for:

- a. Conformance to all governing codes.
- b. The integrity of structures to which the products are attached, including their capability of safely accepting the loads imposed, as evaluated by a qualified engineer.
- c. Using appropriate industry standard hardware as noted above.

SAFETY INSTRUCTIONS: All governing codes and regulations and those required by the job site must be observed. Always use appropriate safety equipment such as eye protection, hard hat, and gloves as appropriate to the application.

CADDY, CADWELD, CRITEC, ERICO, ERIFLEX, ERITECH and LENTON are registered trademarks of ERICO International Corporation.

TECHNICAL SUPPORT:
www.erico.com



CFS274_F

1 of 2


© 2005 ERICO, INC.

ERICO






MP34P (FOR 3-GANG INSTALLATION)



FOR 4-GANG INSTALLATION:




MPAL2

The MPAL2 can also be used as an alarm box mount.

NOTE:
Check with local code authority before using as an alarm mount.

USE OUTSIDE HOLES FOR ALARM BOX INSTALLATION



INSTALL PER PAGE ONE



TECHNICAL SUPPORT:
www.erico.com

CFS274_F

2 of 2

© 2005 ERICO, INC.

ERICO